



FIX-OUT

MUTE

15555

USER MANUAL
HYPERION P1



CANOR, spol. s r.o., Družstevná 39, 080 06 Prešov, Slovakia
Tel./Fax: + 421 51 7710 396,
canor-audio@canor-audio.com / www.canor-audio.com

CANOR HYPERION P1 tube preamplifier user manual



Dear music lover,

thank you for purchasing our CANOR HYPERION P1 tube preamplifier.

To preserve and maintain the best characteristics of your amplifier, we recommend you carefully read the following lines.

Safety instructions

Please read before putting the device into operation

1. Read the instructions – all safety information and instructions should be read before using the amplifier.
2. Keep the user manual – the safety and user instructions manual should be stored for later use.
3. Follow the instructions – all safety and user instructions should be followed.
4. Water and moisture – HYPERION P1 preamplifier should not be placed near water, for example near bathtubs, swimming pool, kitchen sink, etc...
5. Accessories – do not use accessories not recommended by the manufacturer.
6. Placement – do not place a device on an unstable pad. The device may fall, which can cause serious injuries to children or adults and damage to the device. Use only pads or racks recommended by the manufacturer or pads sold to dealers with this device. Any placement of the device should be in accordance with the manufacturer's instructions and only accessories recommended by the manufacturer should be used.
7. Ventilation – the unit should be placed the way to ensure proper airflow. That means it is not allowed to place the amplifier on a sofa, or on upholstered furniture. The amplifier may not be covered over when in operation; it would otherwise prevent proper airflow around the vent holes of the amplifier.
8. Heat – amplifier must be placed so as to avoid the heating effect from heat sources, for example, radiators, stoves, or other heat-producing equipment. The distance from the back wall of the unit may not be less than 20 cm, and 20 cm above the area of HYPERION P1 may not be any barrier. Alongside the unit should be ensured 20 cm minimum distance from other objects.
9. Power source – the device must be connected only to a main supply for what it is designed for.
10. Power cord – it is necessary to pay particular attention to a power cord, it must be positioned in order to avoid setting foot on it and ensure it is protected against mechanical damage.
11. If you do not use the amplifier for a longer period of time – you should disconnect the power cord from the mains supply, or at least turn off the main power switch located on the back panel.
12. Objects containing liquid – do not place these objects (vases, flowerpots), so that they can fall down on the amplifier and, eventually, prevent the liquid from being leaked out on the amplifier.
13. Damages requiring service – equipment should be repaired only by qualified service in the event that:
 - a. power cord is damaged.
 - b. device dropped into the water or was poured.
 - c. device was exposed to rain.
 - d. device works incorrectly.
 - e. device fell down on the ground or is otherwise mechanically damaged.
14. Repairs – all repairs must be entrusted to a qualified service.
15. General warning – use the device only in accordance with this user guide.

The manufacturer declines any liability should these safety measures not be observed. To help you avoid an electric shock, do not expose the amplifier to rain or moisture!

Delivery content

- Shipping packaging
- Canor HYPERION P1 preamplifier
- Remote Control
- Power cord
- Feet felt pads, spikes and spike shoes
- Set of precisely selected 6H30 tubes.
- Textile gloves
- TX20 screwdriver/screws
- Canor HYPERION P1 user manual and tube installation guide

To eliminate vibrations, you can install the spikes and spike shoes on the standard flat legs of the device. In order to do so, just peel off the felt from the standard flat legs and screw the spikes in. Spikes and spike shoes are included in the device package.

FRONT PANEL:

- **POWER** – turning on and off the amplifier
- ▲ – input selector
- ▼ – input selector
- **MUTE** – instant muting of the volume / subsequent pressing results in default volume
- **FIX.OUT** – activates fixed outputs: XLR = IN4 or RCA = IN9
The display indicates: NO FIX / RCA FIX / XLR FIX
- **DIMM** – sets the display brightness in steps. From a turned-off display to its maximum brightness. After turning it on, the display is in its middle brightness level. In the state of a turned-off display while operating the device with function keys the display lights up and after a few seconds, the display turns off again.

BACK PANEL:

- **LEFT / RIGHT OUTPUTS** – 2pairs of XLR and 1pair of RCA
- **LEFT / RIGHT INPUTS** – 4pairs of XLR and 5pairs of RCA
(one pair of XLR or one pair of RCA selectable also as FIX.OUT)
- **TRIGGER OUTPUTS** – outputs for triggering cables
- **POWER** – mains power inlet/mains switch with mains fuse 5x20 T1A

REMOTE CONTROL is equipped with features for the amplifier/preamplifier and a CD player.

(amplifier / preamplifier buttons):

- **ON/OFF** – turning on and off the amplifier
- **DIMM** – sets the display brightness in steps.
- ◀IN – input selector
- IN▶ – input selector
- - **VOLUME** + – volume control keys
- **MUTE** – instant muting of the volume

(CD player buttons):

- **ON/OFF** – turning on and off the amplifier
- **DIMM** – sets the display brightness in steps.
- |<< **BACKWARD** – one short press jumps to the beginning of a track. If playback time lasts longer than 5 seconds, further pressing results in jumping one track back. When pressed for a longer time playback moves smoothly backwards.
- >>| **FORWARD** – one short press jumps one track forward, when pressed for a longer time, playback moves smoothly forward.
- ▶|| – resumes and pauses CD playback
- ■ – ceases CD playback
- **INPUT** – input selector
- **REPEAT** – allows you to cyclically opt for single track repeat, entire disc repeat or disable repeat



Basic functions of reproduction

Plug the power cord into HYPERION P1. Turn on the preamplifier with the Power Main switch, which is located on the back panel. When you turn on the main switch, the HYPERION P1 will set into standby mode - the red LED diode on the front panel lights up. After pressing the Power button on the front panel, the controlled turning-on sequence gets initiated, which consists of cooling and preheating the tubes, thereby extending their life span. The cooling cycle is also carried out when the unit is turned off. If the main switch on the back panel is not turned off, i.e., after turning off via the button on the front panel, the 45-second countdown to cooling without indication begins. If you turn on the unit at this time, the cooling will continue and will be indicated by a flashing red LED. When the cooling cycle is over then the main transformer gets connected and then the slow start-up of voltage begins.

This cycle lasts 45 seconds and then the red LED stops flashing, and an output relay connects the signal to the input if the main power supply does not get disconnected.

You can connect both 4- and 8-Ohm loudspeakers. The amplifier has separated terminals for each type.

Guarantee conditions:

Your CANOR HYPERION P1 tube preamplifier is guaranteed against any defect in materials and workmanship for a period of 24 months from the date of purchase except for audio vacuum tubes that are covered by warranty for a period of three months.

The warranty only applies if an original proof of purchase and acknowledged certificate of warranty can be furnished. The warranty covers defects in materials and labour but does not cover misuse, unauthorized modifications, and external causes such as acts of nature.

European Community Directives

This product is designed and manufactured to comply with existing laws of the European Community. This product is certified by a testing laboratory and bears the CE mark.

Caution!

The Waste Electrical and Electronic Equipment Directive Regulation of the European Union 2002/96/EC governs the issue of separate waste collection.

This device may not be disposed of in the unsorted municipal waste. Devolve the appliance upon a collection centre for recycling and disposal of electrical and electronic equipment waste. Correct disposal of waste does not cause negative impacts on the environment and human health. You will thus contribute to the protection of the environment.

Specifications:

Gain (XLR OUT):	11 dB
Output Impedance:	< 150 Ohm
Frequency response:	10 - 80 000Hz \pm 0,1dB
Input impedance:	30 kOhm
Inputs:	4 x XLR / 5x RCA (one pair selectable as FIX.OUT)
Outputs:	2 x XLR / 1x RCA
Total Harmonic Distortion:	<0,005% (1 kHz, 2V RMS) XLR <0,3% (1 kHz, 49V RMS) XLR
Channel separation:	>110dB
Signal-to-noise ratio:	>115dB (20 Hz – 80 kHz)
Tube Complement:	4 x 6922, 2x 6H30PI
Power:	230V / 50-60Hz / 180VA
Dimensions (WxHxD):	450 x 190 x 465 mm
Weight (Gross):	35 kg





www.canor-audio.com